
Fiat Spider - 2000

**North American Version** 



#### SERVICE NETWORK

When your car needs service look for the sign which identifies all authorized Fiat Dealers where trained personnel, specially designed equipment and facilities are available.

Our organization is at your full disposal for any suggestion or advice you may need.

#### SPARE PARTS

Authorized FIAT parts are the best guarantee for top performance and satisfactory operation of all components.

When ordering, please quote (see page 2):

- -- Car Model.
- Number for Spares.
- Part Number(s) of Spare (s) Ordered.

#### **BREAK-IN RECOMMENDATIONS**

Current progress in design and manufacturing technology is so advanced that no hard-and-fast rule need be given for break-in. However, a few simple rules should be followed for the first 1000 miles:

- Avoid fierce accelerations soon after starting and allow time for the engine to warmup (a good habit even after break-in).
- Do not fully depress the accelerator pedal and avoid high engine speeds, when operating in the lower gears, that is, never allow the tachometer pointer to move into the yellow sector indicating high rpm rates.

- Change your road speed occasionally, especially on long trips. Avoid long drives at constant high or low speeds.
- Downshift whenever necessary to cope with driving conditions on route: you will avoid engine lugging at excessively low rpm.
- Avoid, if possible, severe stops at sustained speeds during the first few hundred miles: brakes will set properly and improve their life and effectiveness.

Remember that satisfactory operation and long life are dependent to a great extent on the care with which the car is handled during break-in.



# CONSUMER INFORMATION

In the **FIAT Spider-2000** series, the following models are available. For information on the vehicle you have purchased, please refer to the tables in the line whose number is encircled in red\*.

Line	Models	Stopping Distance	Tire Reserve Load	Acceleration & Passing Ability
-1	Spider-2000	1	2	3
2	Spider-2000 Automatic	1	2	4
3	Spider-2000 - California Version	1	2	5
4	Spider-2000 Automatic - California Version	1	2	6


### PERFORMANCE DATA DETERMINED ACCORDING TO FEDERAL STANDARDS

<sup>\*</sup> If no red circle appears, please ask your dealer to encircle the proper number.

# VEHICLE STOPPING DISTANCE

This figure indicates braking performance that can be met or exceeded by this vehicle, under different conditions of loading and with partial failures of the braking system. The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

TABLE 1 - Spider 2000 (all versions)



## TIRE RESERVE LOAD

This table lists the tire size designations recommended by the manufacturer for use on this vehicle, with the recommended inflation pressure for maximum loading and the tire reserve load percentage for each of the tires listed. The tire reserve load percentage indicated is met or exceeded by this vehicle.

WARNING. Failure to maintain the recommended tire inflation pressure or to increase tire pressure as recommended when operating at maximum loaded vehicle weight, or loading the vehicle beyond the capacities specified on the tire placard affixed to the vehicle, may result in unsafe operating conditions due to premature tire failure, unfavorable handling characteristics, and excessive tire wear. The tire reserve load percentage is a measure of tire capacity, not of vehicle capacity. Loading beyond the specified vehicle capacity may result in failure of other vehicle components.

TABLE 2 - Spider 2000 (all versions)

TABLE E SPINS 1995 (un reserve)				
Recommended tire size designati	165 SR-13			
Recommended cold inflation pressure for maximum loaded vehicle weight	Front p.s.i.	28		
Tire reserve load percentage (1)	%	23.1		

<sup>(1)</sup> The difference, expressed as a percentage of tire load rating, between (a) the load rating of a tire at the vehicle manufacturer's recommended inflation pressure at the maximum loaded vehicle weight and (b) the load imposed upon the tire by the vehicle at that condition.

# Fiat Spider - 2000

Carburetor System

This Manual provides the information necessary for satisfactory operation and maintenance of your car.

We wish you pleasant motoring and trust the information provided will help to ensure the long life and safety of your car.

operation maintenance specifications


Appendix:


Fuel Injection System

# KEYS

Each vehicle is provided with two keys in duplicate; quoting the number stamped on each key is essential to obtain a replacement from FIAT's Sales Organization.

- A For ignition switch
- B For door and trunk locks.







# IDENTIFICATION DATA

# ■ Identification Plate


- a Chassis Type (124 CS2)
- b Chassis Number
- c Order Number for Spares (preceded by letter A which identifies the North American Version cars and must warrys be quoted in the orders for spares)
- d Body Paint Color Number
- e Engine Type (132 C3.040)
- f Top Paint Color Number








- Engine Type (132 C3.040) and Identification Number Punched on crankcase, near oil filter mount.
- Chassis Type (124 CS2) and Identification Number Punched on engine compartment bulkhead (permanent structure) right side.
- F.M.V. Safety Standard 115 Tag Type of vehicle and chassis number, located on panel top between instrument cluster and windshield.
- F.M.V. Safety Standard 110 Tag Tire data and car capacity, located on R.H. door pillar, above striker.




■ B) Vehicle Emission Control Information Label - Located on left door pillar.


■ E.P.A. Regulations Conformity Tag - Air pollution control specifications for correct engine tuneup and adjustments, located in engine compartment, on cowl.












# INSTRUMENTS AND CONTROLS

- 1 Lighting switch, three-position
- 2 Turn signal lights switch lever
- 3 High/Low beams change-over switch lever
- 4 Inspection lamp receptacle
- 5 Instrument cluster
- 6 Horn button
- 7 Steering lock ignition switch
- 8 Windshield washer and wiper switch lever, three-position
- 9 Air outlets
- 10 Windshield wiper sweep rate knob
- 11 Low brake fluid level/hand brake ON indicator
- **12** Vehicular hazard warning signal indicator

- 13 Fasten belts indicator and buzzer
- 14 Knob switch and rheostat for instrument cluster lighting
- 15 Glove compartment
- 16 Glove compartment lock
- 17 Utility recesses (two)
- 18 Power window switches housing
- 19 Courtesy light with switch
- 20 Gearshift lever
- 21 Floor tray
- 22 Lever controlling air flow through outlets 9 and/or under dash
- 23 Cigar lighter

- **24** Optional radio housing blanking lid
- 25 Ash tray
- 26 Hand brake lever. To release the lever press in button on top of handgrip
- 27 Two-speed heater fan switch, three-position
- 28 Air volume control lever
- 29 Air temperature control lever
- 30 Accelerator pedal
- 31 Service brake pedal
- 32 Clutch pedal
- 33 Fusebox
- 34 Hood release emergency cable
- 35 Hood catch release lever

# **OPERATI**



Instrument Cluster

- a) Fuel Reserve Indicator (Red) -Warning that the fuel supply available in the tank is between 5 and 7.5 liters  $(1^{1}/_{3} \text{ to 2 Gals})$ .
- b) Fuel Gage
- c) Speedometer This instrument (which includes the odometer) is factory-sealed: any tampering by unauthorized persons will invalidate the warranty.
- e) Trip Recorder
- Water Temperature f) Engine Gage - If the pointer enters the red area it means that the engine is overheating: it will then be necessary to immediately rev down the engine to idle speed (do not switch off). Should the pointer remain on the red area, contact the nearest

FIAT Dealer for a cooling system check (including fan circuitry).

- g) Tachometer Electronically-operated from the ignition distributor. The yellow area indicates maximum engine speed for all gears whereas the red area shows dangerous engine operating speeds.
- h) Type of Fuel Used (see page 33)
- **Cluster Panel Mounting Knobs** (Four)
- Parking and Tail Lights Indicator (Green)
- m) Turn Signal Arrow Indicator (Flashes green)
- n) High Beams Indicator (Blue)
- o) Trip Recorder Zeroing Knob -Turn knob clockwise but never when car is running.
- p) Battery Charge Indicator (Red) With engine inoperative, and ignition key in position MAR, the charge indicator is on and must go out when engine is started;

should indicator turn on while engine is running, this is a warning of a fault in the battery recharging system: turn immediately to a FIAT Dealer for assistance.

- q) Insufficient Oil Pressure Indicator (Red) - The light should go off when oil pressure is sufficient to ensure adequate engine lubrication.
- r) Clock Reset Knob Push and turn clockwise making sure that it springs back when released.
- s) Quartz Crystal Clock

#### **Lighting Switch**

Up = All lights OFF.

With Ignition Key at MAR:

Down = Parking and tail lights,
headlight low or high beams and
flashers (main beams).

With Ignition Key Removed:
Center (night parking only) = Parking and tail lights.
Down = All lights OFF.


Fasten Belts Indicator (Red) and Buzzer - Both are operative for a few seconds when a starting attempt is made with seat belts (driver and/or passenger) unfastened.

# Low Brake Fluid Level/Hand Brake ON Indicator (Red)

With ignition key at MAR the indicator lights up to warn the driver that the bulb is efficient. In case the indicator remains ON it means either that the hand brake lever is pulled upwards (brake applied) or that the brake fluid level is too low.

Should the indicator turn on while the vehicle is moving, stop and check the fluid level in reservoir. If the level is too low, great care should be taken when applying the brakes and the nearest FIAT Dealer contacted for a brake system check.

Vehicular Hazard Warning Signal Switch - Turns ON (independently of key position in lock switch) the front and rear turn signal lights which will all flash simultaneously to warn of the presence of the vehicle stopped on the road.





# Windshield Wiper/Washer Switch Lever

- a = Wiper off
- b = Wiper On-Off intermittently (particularly useful in drizzly weather)
- c = Wiper on continuously

Lifting the lever towards steering wheel, whatever its position, will switch on the washer.

Windshield Wiper Sweep Rate Knob - Provides high or low sweep rates in either wiper continuous or intermittent operation, depending on the position of wiper lever switch.





Low beams


II = High beams

By lifting the lever towards steering wheel headlight high beam flashes are obtained even with all lights out (Daylight signals).

Turn Signal Lights Switch Lever Automatically trips back to OFF.

R = Right turn

L = Left turn




**Steering Lock Ignition Switch** (\*) (See page 16 for starting procedure instructions)

 $\mathbf{MAR}\ (Run) =$ Engine ignition ON and accessories energized

AVV (Start) = Engine starting

ST (Stop) = Steering post anti-theft lock in. Key removable




**Remove Key Buzzer** - Operates when the steering wheel side door is opened to leave the car and the ignition key is forgotten in the lock switch.


**Gearshifting Pattern** - To engage reverse (**R**), press the lever and shift as indicated by the gating pattern.


**Note:** The use of fifth gear over 45 mph improves fuel economy.

The total or partial removal of key will lock the steering post even if car is in motion. To facilitate the disengagement of steering post lock, slightly rock the steering wheel while rotating the key. Key must not be left in position MAR when engine is inoperative and must be removed only when leaving the car, especially if unattended.

(\*) Even with key removed (position ST) the following circuits are still energized: courtesy lights; horns; cigar lighter and housing indicator; vehicular hazard warning signal; remove key buzzer; clock; inspection lamp receptacle.







35818

Inner Rear View Mirror - Collapsible, with anti-glare (Day/Night) position controlled by a lever. If the mirror comes off its seat, following an impact, refit by engaging spring B on stud A — make sure the two location dowels are properly registered with relevant seats — and press on base C. Engagement is of the snap-on type.


Outer Rear View Mirror on steering wheel side door adjustable from driver's seat, by means of lever B.


### Cigar Lighter


To operate, press in knob A: after about 15 seconds it will snap out, ready for use. When parking lights are ON, an indicator illuminates the lighter housing.

#### Ash Tray

Raise the lid to open. For periodical cleaning, grab the stubber and take out the tray.







# DOORS

### Opening

**From outside** - Unlock and pull the handle.

From inside - Pull up lever A.

### Locking

**From outside** - Both doors are provided with key-operated locks. Stepping out of the car on the curb side is thus also possible. Always use the key: never lever **A**.

From inside (safety latch) - With door already shut set the lever A down. The lever will thus first insert the safety latch and then snap back to rest.

**Note:** Lubrication of lock cylinders is not recommended. At most, blow some graphite powder into the cylinder keyhole. In cold climates it is recommended to squirt in some special antifreeze fuild for locks. Repeat the operation every time the car is washed or at least every 15 days. If insertion of key in the frozen lock proves difficult, simply warm up the key.

#### **SEATS**

Seats may be adjusted for leg reach after moving control lever **A** downwards.

Once the desired position is found, release the lever and make sure the seat has locked.


The position of the backrest is adjusted by turning knob **B**.



For access to the rear compartment push down lever **C** and tilt backrest downward.

On top of each seat backrest is fitted a headrest: to re-set height pull up or push down as required.

The headrest must be adjusted so as to support the head and not the neck of the occupant.



#### SEAT BELTS

Seat belts provided as standard original equipment are of the 3-point lap type.

Pull belt fully out from retractors without stopping as otherwise it will be necessary to return the belt to the stowed position to release the retractor stop mechanism.

To fasten, fit tongue **A** into buckle **B** until a sharp click is heard.

Adjust the belt snugly around the hips, not the waist, allowing excess webbing to be pulled back into retractor.

To free yourself from the belt restraint: simply press in buckle button **C**.

#### Warning

Before fastening the belts make sure the seats and headrests are properly positioned.

Each belt is intended for use by one adult or one child over 6 years of age.


Occasionally, check that webbing is in good condition.

In the event of an accident, even if the belt you were wearing is apparently undamaged it is suggested that you replace it with a new belt assembly of the same type.

To keep belts clean, wash only, using warm water and mild soap. Rinse and dry thoroughly. Do not use strong detergents and avoid any chemical that may weaken the equipment.

Users are warned to consult the Manufacturers in case of doubt and not to make any alterations of, or additions to, seat belt assemblies and/or anchorages.

# **VENTILATION AND HEATING**




Ventilation and heating are adjustable according to seasonal requirements.

To ensure best comfort to occupants it is important to become familiar with system controls and operation.

#### Admission of Heated or Fresh Air

**Heater fan switch C** is energized only when ignition key is in position MAR.

Pressed in forward = High speed
Intermediate position = Off
Pressed in backward = Low speed



**Lever D** controls the air temperature.

Pulled all back - No heating of air

Pushed all forward - Maximum heating of air

Lever E controls the air volume.

Pulled all back - Maximum air flow

Pushed all forward - No admission

of air

Intermediate positions are used especially when outdoor temperature is low to limit the flow of cold air around heater core.

**Lever F** controls the amount of air flowing through windshield outlets **A** and into front lower area through console outlets **B**.


Pulled all back - Air flows through outlets A only

Pushed all forward - Air flows through outlets **A** and **B** 

#### **Defrosting and Demisting**

For quick defrosting of windshield, pull back completely lever **F**, push forward lever **D** and set lever **E** in an intermediate position. Turn on the heater fan by switch **C**.


**Door window ventilators** are opened by pulling lever **G** and turning upward lock **H**.




#### Frost Precautions


If during cold weather the car must remain inactive for some time at freezing temperatures and the cooling system is not protected with antifreeze mixture, it will be necessary while draining the radiator and jackets to empty also the heater core by shifting lever **D** all forward.


**Note:** If heating proves inadequate, operation of the thermostat on the line from cylinder block to radiator must be checked.












FOLD-AWAY TOP


To lower the folding top, proceed as follows:

- Wind down the door windows.
- Pull down the two latch levers A and release clamps B from latches C securing the top to windshield frame.
- Push the top to the rear, making sure the back window is not pinched by the metal frame.
- Free the rubber strap from the peg on body side and strap the folded top as shown in the figure.





 Place cover F on the folded top well by fitting rear eyelets D on hooks E (page 14) then catches G in detents **H**, spring hooks **I** in holes **L** and snap on the button fasteners **M**.



#### STARTING THE ENGINE

#### Cold Starts

Proceed as follows:

- Move gearshift lever to neutral.
- Depress clutch pedal, especially in cold climates.
- Depress accelerator pedal and release. This will enable automatic choke to come into operation.
- Insert and turn ignition key clockwise to the stop, i.e. position AVV, page 8. As soon as engine is started release key which will snap back to position MAR.
- If the engine stalls, repeat starting procedure.
- Do not step on accelerator pedal until the engine is running smoothly.

- During warm-up the automatic choke will be deactivated progressively.
- Avoid sudden accelerations when engine is cold. At this stage, to reduce engine idle speed before placing the transmission in gear slightly depress and release the accelerator pedal.
- Do not continue with repeated starting attempts. If the engine fails to start or stalls at idling have the fuel and ignition systems checked as soon as possible.

Starting instructions for cars fitted with automatic transmission are given on page 17.

**Note -** Should the engine fail to start, return ignition key back to ST position.

#### Flooded Engine

To deactivate the automatic choke and clear the engine of excess fuel, fully depress the accelerator pedal while cranking to start.

#### **Hot Starts**

If the engine is particularly hot, fully depress accelerator pedal and release it slowly as soon as engine fires. Under normal conditions depress accelerator pedal half way and turn the ignition key.

Do not repeatedly press the accelerator pedal, as each stroke actuates the accelerating pump which, by providing an excessively rich mixture, would make engine starting difficult.

#### STARTING THE CAR

In cold climates idle the engine for a few minutes prior to moving off: this will allow engine oil to reach operating temperature and help its circulation throughout the system.

Gearshifting positions are shown on page 8.

Should engagement of the 1st gear with car stationary prove difficult,

release the clutch a few seconds and repeat the maneuver.

To engage reverse (R) the car must be stationary: from neutral, press and move lever to the right and back.

#### DRIVING THE CAR

Never maintain nor exceed the maximum allowed speeds and do not drive with tachometer pointer steadily on the yellow sector.

Do not travel steadily for long intervals at top speed in any gear.

All red indicator lights should be out while driving.

Do not coast downhill with the clutch pedal depressed, the transmission in neutral or the engine off, as the marginal saving in fuel consumption which may be derived from such practice does not compensate for the resulting loss in brake lining life and

driving safety which is provided by the braking effect of the engine.

Remember that upon switching off the engine, the brake servo is deactivated and, therefore, braking requires more effort.

Do not allow the engine to lug, particularly when driving up steep hills, but shift down in good time to benefit from maximum engine pulling power.

Do not ride the clutch, otherwise slippage and damage will result.

Ensure that both the foot and hand brakes are efficient at all times. After a car wash apply the foot-brake a few times so as to restore full brake effectiveness.

Always apply the foot brake progressively. Remember that wheel locking, especially with an unladen car, will result in dangerous skidding. In case of emergency the hand brake may be used to stop the car.

On wet or slippery roads hard braking will increase the likelihood of wheel locking and consequent inevitable loss of handling control. Instead, use the engine braking effect by engaging a gear lower than would normally be required. Braking, if absolutely unavoidable, should be gentle and progressive and, in any case, simultaneous with engine braking.

On icy roads drive slowly, turn the steering wheel very gently, avoid using the brakes, change gear smoothly and do not drive with the clutch pedal depressed. If the car starts skidding release the accelerator pedal, do not brake, but steer smoothly in the direction of skid; as the car regains its course straighten the wheels and accelerate gently.

Always use tire chains or snow tires before starting a journey on ice or snow covered roads and remember that while snow chains can be fitted to the driving wheels only, studded tires should be fitted to all wheels.

When driving in mist or fog during daylight switch on the parking and tail lights: do not use the high beams.

Before turning or changing lanes, in addition to giving the correct signals glance in the mirrors to ascertain the intentions of the drivers behind you. Before cutting back into your lane after overtaking a vehicle wait until it appears in your inner mirror.

At night when meeting oncoming traffic, keep your eyes on the right side of the road rather than looking straight into the approaching headlights or other light sources: you will avoid being blinded.

#### **PARKING**

Always apply the hand brake when parking and if on a grade, for added safety also shift into first or reverse depending on whether the car is heading up- or downhill.

When the car is left in dark areas always turn on the parking lights: lighting switch pressed halfway in at bottom.

## RECOMMENDED SHIFTING SPEEDS

1st-2nd 2nd-3rd 3rd-4th 4th-5th 15 mph 25 mph 40 mph 45 mph

**Note:** In any case the maximum speed listed on page 51 should never be exceeded.

## AUTOMATIC TRANSMISSION

(Optional Extra)


### **OPERATION**

To obtain any ratio move selector lever **A** to the desired position.

When shifting from P to R, R to P, N to R, D to N or 2 to 1 lift trigger **B** simultaneoulsy. When shifting from **D** to **2** and viceversa do not operate trigger **B**. Light **C** indicates the selected position.

#### **Selector Lever Positions**

P. Park - R. Reverse - N. Neutral - D. Drive - 2. Intermediate - 1. Low.



#### Selector Lever Positions



#### Park

In this position the transmission is mechanically locked but engine starting is possible. Park should not be selected when the car is in motion or stationary in busy car parks where shunting is likely to occur.

Use of the Park position is recommended when parking on flat and sloping ground and before servicing.



#### Reverse

To select Reverse bring the car to a dead stop and release the accelerator pedal (engine idling).



#### Neutral

In this position the engine can be started.



#### Drive

This position is used for normal driving.

The transmission starts in low gear and automatically changes up or down at suitable road speeds according to the position of the accelerator pedal and the demands made by the driver. For quick down-shifting depress the accelerator pedal through its hard spot (kickdown position).

Kickdown permits down-shifting from third to second below 59 to 64 mph or into first below 31 to 34 mph.

Normal change-down from **D** to **2** and **D** to **1** can be obtained by means of the selector lever below 70 mph and 43 mph respectively, without depressing the accelerator pedal.



#### Intermediate

Operation is as described under **D** but no up-shift into third is possible. This may be advantageous when driving over hilly or difficult roads requiring

consistent pull and moderate engine braking.



#### Low (Lock-up in First)

To be selected when driving up and down very steep hills, especially with a trailer on tow, and when maximum engine braking is desired.

When the selector lever is moved to 1 the transmission changes to, and remains in first, regardless of engine speed.

Note: With the engine idling and D, 2, 1 or R selected the car may tend to creep forwards or backwards. This tendency can be obviated by lightly applying the foot brake and may well be advantageous for difficult parking maneuvers.

#### Starting

Before starting the engine move the selector lever to  ${\bf N}$  or  ${\bf P}$ .

Engine starting is not possible with the selector lever in any other position.

Starting instructions not described here are as given on page 19.

Depress the brake pedal without accelerating at all, and move the selector lever to 1, 2, D or R as desired.

Release the hand brake and the foot brake

Depress the accelerator pedal progressively. In **D** the car will move off in first gear and automatically change up as speed is increased.

For maximum acceleration depress the pedal through its hard spot. This causes up-changes to occur at higher road speeds than under part-throttle driving (approximately 40 to 43 mph from first to second and approximately 65 to 70 mph from second to third).

Exceptionally, when maneuvering in confined areas or for hill-holding the driver will find it convenient to use the left foot on the brake pedal and, using this pedal in conjunction with or without the accelerator pedal, a high degree of control is obtained.

During normal driving both the accelerator and the brake pedals should be operated with the right foot only.

#### Towing by Another Vehicle

Proving the transmission is operating satisfactorily, the car may be towed in **N** over distances up to

30 miles and at road speeds not exceeding 30 mph, otherwise gearbox damage may result. If the car is to be towed over long distances, or if the transmission is defective, the car must be towed with the rear wheels raised from the ground or propeller shaft disconnected.

#### Warning

To prevent dangerous over-revving do not exceed the prescribed shifting speeds.

#### Stopping


To stop the car release the accelerator pedal and apply the brakes.


No further action is needed for short stops, as first gear will be automatically re-engaged when moving off again. On upgrades, hold the car exclusively by pressing the brake pedal.

For long stops, move the selector lever to  ${\bf N}$  and apply the handbrake.

When leaving the car unattended shift the selector lever to **P** after coming to rest. Thus, the transmission will be locked.







### WHEEL CHANGING

If possible, place the vehicle on level ground and lock rear wheels by the hand brake.

Take out tool box **A** and jack **B** in trunk: release strap **C** first.

Take out spare wheel  ${\bf D}$  proceeding as follows:

- Roll up mat E.

 Free the two catches G and tilt away cover F for access to the well of spare wheel.

Slacken about one turn the four wheel fixing bolts, using the wheel wrench.

Place the jack under the car as shown, that is, at the bracket nearest the wheel to be removed.

Make sure the ground is sufficiently hard (that is, jack base does not sink during the lift action).

Fit the socket of hand lever  ${\bf N}$ , on hex. shank  ${\bf O}$  and start jacking up.

**Note:** Operation of the jack until it contacts the lift bracket under floor may also be carried out by turning handwheel **P**, welded onto the hex. shank. This applies also to lowering the car.

Keep actuating the lever up and down until the wheel to be changed clears the ground.

Back out completely the bolts and remove the wheel. Place the bolts inside the upturned wheel cap: this will prevent the threads from getting fouled with dirt, a frequent cause of difficulties at reassembly.

Fit the spare wheel seeing that the location dowels fit into two of the location holes in wheel disk.

Fit and tighten uniformly the wheel fixing bolts in criss-cross sequence.

Remove the jack hand lever and fit it back on hex. shank with socket turned the other way around. Then actuate the lever in the usual manner and lower the car.

Fully tighten the wheel bolts in criss-cross sequence and fit back the wheel cap.


Check that the newly fitted tire is inflated to the correct pressure.

When repositioning the jack in the trunk make sure shank **O** is properly housed and strap **C** is correctly buckled to avoid rattling.

**Important.** - Every wheel is balanced in the Factory by the addition of proper plates on rims.



When tires are replaced or refitted, the wheels must be rebalanced statically and dynamically.



# JACKING-UP AND TOWING

When either the front or rear end of car must be raised with a garage jack, it is necessary to fit jack head under front suspension cross rail, interposing a suitably thick (abt. 3 cm -  $1^{1}/_{4}$  in.) wooden block, or rear axle bulge.

If car needs towing with a rope this must be attached to the specially provided front brackets.



# MAINTENANCE

This section includes all periodical maintenance operations essential for continued effectiveness of the car.

The lubrication, cleaning, inspection and adjustment operations recommended in relation to given mileages are listed on a General Maintenance Schedule. Reference is made to the pages where each operation is described.

The Owners Warranty and Service Book contains a free service coupon. This service should be performed at 1 500 miles.

Failures, other than those resulting from defects in material or workmanship, which arise solely as a result of owner abuse and/or lack of proper maintenance are not covered by warranty.

Particular stress is laid on the importance of reporting to a FIAT Dealer for all the maintenance operations so marked:

For oil grades not mentioned here, see the Fill-up Data Table.

### EMISSION CONTROL SYSTEMS

The maintenance operations necessary to ensure the proper functioning of the vehicle emission control systems are printed in red for immediate identification both in the General Maintenance Schedule and in the paragraphs of this section.

The engine tuneup and adjustment specifications are also listed on the E.P.A. Regulations Conformity Tag, located in the engine compartment (see pages 3 and 54).

For all these operations it is also recommended to refer to the instructions specified in the Owners Warranty and Service Book.

#### NOTICE

Besides the routine maintenance operations listed in the Schedule, this section describes other operations which must be performed only in special cases of defective operation of mechanical units.

# GENERAL MAINTENANCE SCHEDULE

■ We recommend that all operations so marked be entrusted to the Fiat service network

	OPERATIONS	See page	Every 15 000 miles	Every 30 000 miles	Every 45 000 miles
			*		
	Tappet clearance: check and adjust, if nec.	26	•	•	•
	Timing belt: check and change, if nec.	27		•	
350	Ignition distributor: check and, if nec., change cap and rotor	28	•	•	•
	check advance mechanism and change, if nec	28			•
	check ignition timing and adjust, if nec	28	•	•	•
	Spark control modulation device: check components	28			•
	Ignition system: check condition of wires and connections; change if nec	28	•	•	•
	Spark plugs: change	28	•	•	•
	Carburetor: check idle speed and CO concentration, adjust if nec.	29	•	•	•
	check throttle and choke control linkage, idle stop solenoid and wire	29	•	•	8
M	Power valve thermovalve and vacuum accelerating pump: check lines	30	•	•	•
	Fuel filter: replace unit	30	•	•	•
100	Air cleaner: check and clean cartridge	30	0		0
	renew cartridge	30		•	
	check temperature sensing unit operation	30	. •		•
	Crankcase emission control system: clean, wash and check	31	•		
	Fuel evaporative emission control system: check components and renew if nec	32	•		•
	Exhaust emission control system: check vacuum lines of reed valve, gulp valve, EGR valve				
	wires and connections of the three-way electrovalve	33	•	•	•
	check air pump, lines and fittings	33	•	•	•
	check gulp valve operation	33		•	
	Brakes: check for wear, inspect lines and hand brake effectiveness	36	•	•	•
	Brake fluid: Top up	36	•	•	•
	Clutch: check pedal height and adjust if nec.	37	•	•	
	Transmission (manual or automatic) and axle: change oil	38		•	•
	Steering linkage and suspension articulations: check for wear and play	39	•		•
	Wheel bearings: check lubrication	39	-		•
	Body: Lubricate door locks and hinges and other recommended items	40			
	body. Eablicate door looks and imiges and other recommended items		- 1	-	-

## SPECIAL MAINTENANCE

OPERATIONS	See page	Every 500 miles	Every 3 000 miles	Every 7 500 miles
Engine oil: check level	26 36	•		
Cooling system: check coolant level	36	•		
Automatic transmission (where fitted): check fluid level	38	•		
Tires: check pressure	40 43-44		•	
Battery: check electrolyte level and inspect posts and clamps  Engine oil and filter: change oil and filter	26			•
* Air cleaner and spark plugs: check, clean and renew if nec.	28-31			•
* Ignition timing, idle speed and CO concentration: check and adjust if nec	28-29			•

<sup>\*</sup> Operations recommended when the car is driven in heavy traffic conditions or dusty areas.

# **Lubricant Designations**

FIAT	INTERNATIONAL	FIAT	INTERNATIONAL
	Single-grade low-ash content detergent oils - API Service SE, to MIL-L-46152 and above the CCMC European Sequence	GI/A	A.T.F DEXRON II Type for automatic transmission
VS+		W 90/M	<b>SAE 80 W/90 EP Oil</b> to MIL-L-2105 B
ZC 90	SAE 80 W/90 Oil with anti-wear	Jota 1	Lithium-base Grease N.L.G.I. No. 1
20 90	additives, for manual transmission	MR 3	Lithium-base Grease N.L.G.I. No. 3

#### **ENGINE**

#### Engine Oil

Every 500 miles or weekly With engine cold, check oil level which must always be between the Min and Max marks on dipstick, and top up if required.

Every 7 500 miles or every six months at most - Replace oil with engine well warmed up.

Drain all used oil through plug A. Oil should of course be changed also in relation to the grade used and outdoor temperature (Singlegrade or Multigrade) as shown in the Fill-up Data Table.

#### **Engine Oil Filter**

Every 7 500 miles or at every engine oil renewal - Unscrew filter A from its support on crankcase, and replace.


Before fitting a new filter on the support, wet its seal with engine oil. Screw on the filter: once the seal contacts the support, tighten 3/4 turn


#### Tappet Clearance

Every 15 000 miles or whenever valve operation becomes noisy. Check clearance between tappets and cams. Specified clearance, with cold engine, is .45  $\pm$  .04

mm (.0177  $\pm$  .0016 in.) for intake and .50  $\pm$  .04 mm (.0196  $\pm$  .0016 in.) for exhaust valves.







#### Valve Gear Timing



It is advisable that you consult a FIAT dealer whenever valve gear or timing checks become necessary.

#### **Timing Belt**



Every 30 000 miles - Check the timing belt. Following belt removal or slackening, always renew the belt. Under no

circumstances must the belt tension be adjusted following its initial installation.


Note: To renew the belt simply slacken the tensioner roller retaining nut.

Do not interfere with the tensioner pivot screw immediately below.

After renewing the belt fully retighten the nut.

#### Valve Gear Drive

1. Valve timing pointers - 2. Intake camshaft drive pulley - 3. Timing belt -4. Exhaust camshaft drive pulley - 5. Roller retaining nut - 6. Tensioner spring -7. Tensioner roller - 8. Tensioner retaining screw - 9. Oil pump drive pulley - 10. Crankshaft sprocket.




#### **Ignition Distributor**

The ignition distributor is of the inductive discharge type.

Every 15 000 miles - Check cap A and rotor B for cracks, carbon deposits or erosions: change parts as required.

Every 45 000 miles - Check the advance mechanism: change parts as required.



# **Ignition Timing**


Every 15 000 miles or when the camshaft and/or distributor have been removed: check static advance.

With the engine at 800 to 850 rpm (manual transmission) or at 700 to 750 rpm (automatic transmission) static advance should be  $10^{\circ} \pm 1.5$ .

If the car is used mainly in heavy traffic conditions or dusty areas check ignition timing every 7 500 miles.

Ignition timing:

 $A=10^{\circ} (Adv.); B=5^{\circ} (Adv.); C=0^{\circ} (TDC)$ 



#### Spark Control Modulation Device

Every 45 000 miles - Check fittings and vacuum lines of thermovalve, delay valve and capsule.



#### Ignition System Wiring

Every 15 000 miles - Check all wires for cuts, burns, chafing or perforations. Change parts as required. Terminals must be well

secure and ground connections effective.

#### Spark Plugs

Every 7 500 miles (\*) Clean spark plugs and remove all deposits. also in the recess between

central electrode porcelain liner and body (sand blasting is recommended). Change if necessary.

Check if electrode gap is as specified: .6 to .7 mm (.023 to .027 in.) for standard-type plugs and .7 to .8 mm (.027 to .031 in.) for resistor-type plugs. Adjust if necessary.

(\*) Operations recommended when the car is driven in heavy traffic conditions or dusty areas.



**Every 15 000 miles** - Fit new spark plugs. These must be of the type specified: if their thermal rating is inappropriate engine

malfunction and/or failures may occur.

#### Carburetor

Carburetor adjustments must be performed after checking the ignition system.

It is advisable that you consult a Fiat dealer when carburetor develops trouble.

Every 15 000 miles - Check throttle control linkage for excessive play or binding: correct as required.

Also check the choke for proper operation: with engine warmed up the strangler valve in carburetor barrel must be wide open.

Check idle stop solenoid and wire; change parts as required.

Every 15 000 miles (\*) - Check carburetor idle setting and CO concentration, and adjust if necessary.

CO concentration reading should be 1 to 2.5% according to EPA Regulations Conformity Tag, when checked at

 $850\pm50$  rpm - manual transmission - or at  $750\pm50$  rpm - automatic transmission - Checking and adjustment procedures are as follows:

#### **Procedure A**

- Pinch off the air injection hose upstream of check valve.
- Start the engine and warm it up.
- Properly connect the tachometer.
- Insert into the tailpipe the sample probe of a CO tester properly calibrated and warmed up.
- Apply the hand brake or bring selector lever to « Drive » position (automatic transmission).




- If the reading on the instrument is not according to the above data, correct through idle speed adjusting screw A (turn it clockwise to increase rpm and counterclockwise to decrease), then through mixture adjusting screw B (turn it clockwise to decrease the CO% and counterclockwise to increase it).
- Recheck if the rpm are according to the prescribed valve; if not repeat the above adjustments.
- Finally, restore the air injection.

#### Procedure B

- Start the engine and warm it up.
- Properly connect the tachometer.
- Apply the hand brake or bring selector lever to « Drive » (automatic transmission).
- Adjust engine speed as per procedure A acting on idle speed adjusting screw (turn it clockwise to increase rpm and counterclockwise to decrease).
- Turn mixture adjusting screw B up to obtain the maximum engine speed.
- (\*) If the car is used mainly in heavy traffic conditions or dusty areas check idle setting and CO concentration every 7 500 miles.

- Bring engine speed back to normal value through screw A.
- Turn screw B so as to decrease engine speed by:
   45 to 55 rpm (manual transmission)
   20 to 25 rpm (automatic transmission)
- Restore engine speed through screw
   A.

tion and connection tighteness of power valve and accelerator pump thermovalve vacuum lines: change parts as required.



#### Fuel Filter


Filter A from fuel lines and change. Make sure the new filter is properly positioned as

indicated by arrow **B** on filter body. Also check lines and connections for satisfactory condition and tightness.

#### Air Cleaner

The engine is fitted with a thermal air cleaner with a wax-type temperature sensing unit.

Its main characteristic consists in keeping constant the temperature of the air entering the engine.



Every 15 000 miles (\*) - Check, clean

and, if necessary, change cartridge **C**.

To gain access to the cartridge remove cover **B** by undoing nuts **A**.

Every 30 000 miles - Change air cleaner cartridge **C**.

Service

Every 15 000 miles - Check air cleaner throttle valve and return spring operation. Renew if necessary.

(\*) When the car is used mainly in heavy traffic conditions or dusty areas change fuel filter or air cleaner cartridge every 7 500 miles.



## EMISSION CONTROL SYSTEMS

Vehicle emissions are controlled by various devices that make up the crankcase emission control system (CEC), the exhaust emission control system (EEC) and the fuel evaporative emission control system.

The maximum efficiency of the emission control systems is dependent upon the performance of the recommended maintenance.


Any modification of the emission control systems is subject to Federal laws and regulations and may incur penalties.

#### Crankcase Emission Control System

It is a closed system designed to prevent any emission of blow-by gases into the atmosphere.

#### Operation principle:

- At closed throttle (see detail 4 a) the blow-by gases are drawn into the intake manifold through the calibrated orifice of control valve incorporated in carburetor.
- At wide open throttle (see detail 4b) part of the blow-by gases is drawn



1. Emission feedback line to air cleaner - 2. Flame trap - 3. Air cleaner-to-control valve line - 4. Control valve - 4a. Control valve in engine idling condition - 4b. Control valve in engine beyond idle condition - 5. Intake manifold - 6. Sump-to-air cleaner line - 7. Cyclone liquid/vapor separator - 8. Oil drain line into sump.

into the intake manifold through the open duct of the control valve. The remainder flows directly to the "clean" side of the air cleaner.

#### Every 15 000 miles



Clean and wash the recirculation system, including the flame trap, using the proper solution.


Also check all lines and connections for satisfactory condition and intake manifold for proper tightness.

#### Fuel Evaporative Emission **Control System**

The release of fuel vapors from tank and carburetor bowl into the atmosphere is prevented by a proper system through which they are conveyed to an activated carbon trap in engine compartment where they are adsorbed. During engine operation a hot air stream regenerates the activated carbon from which the gasoline vapors are extracted and conveyed to the intake manifold.

The system consists essentially of: Sealed filler cap. Limited-filling tank. Vapor-liquid separator.


Carburetor bowl vapor vent line. Two-way valve. Fuel tank vapor vent line. Activated carbon trap.



#### Every 15 000 miles



Check valves, lines and fittings for satisfactory condition and change parts as required.



1. Carburetor bowl vapor vent line - 2. Activated carbon trap - 3. Fuel tank vapor vent line - 4. Line to engine intake manifold - 5. Calibrated orifice - 6. Two-way valve - 7. Vapor vent line - 8. Vapor-liquid separator - 9. Sealed filler cap -10. Fuel tank (limited-filling type).

### **Exhaust Emission Control System**

This system consists essentially of:

- An air injection system
- An exhaust gas recirculation system (EGR)
- A catalytic converter

An engine-driven air injection pump with built-in centrifugal air cleaner sends an air stream to a one-way check valve and from this, via a gallery in cylinder head, to the exhaust of each cylinder.

A certain amount of the air stream is branched off from the pump and conveyed to the air cleaner where a pressure relief valve cuts in whenever the engine is lugging or when the air pressure exceeds the prescribed value.

To reduce  $No_x$  emissions part of the exhaust gases is recirculated through an EGR valve from the exhaust manifold to the intake manifold.

To prevent backfiring in the exhaust system during sudden decelerations a mixture control valve (Gulp valve) supplies additional air to the intake manifold. A catalytic converter then

further oxidizes the hot gases during post-combustion process.

The system also includes a specially calibrated carburetor and an ignition distributor with appropriate centrifugal and vacuum-assisted advance.

#### WARNING

#### Fuel Refilling

Strictly adhere to the label on instrument panel and on filler cap.

# UNLEADED FUEL ONLY

Leaded fuel will damage the catalytic converter beyond repair. Always refill at Service Stations which carry unleaded fuel (small pump nozzle).

Every 15 000 miles - Check vacuum lines of gulp and EGR valves for satisfactory condition. Fittings of electrovalve must

be well secured and free from damage. Change parts as required. Check «Gulp» valve operation: during decelerations no back-fires shall occur.


Renew components, if necessary.

**Every 15000 miles** - Inspect the air injection pump for defects or damages. Check condition of lines and fittings. Renew parts if necessary.



# Exhaust Emission Control System Diagram

- 1. Advance capsule
- 2. Ignition distributor
- 3. Advance capsule vacuum tapping line
- 4. Exhaust gas recirculation tapping line
- Thermal air cleaner
- 6. Reed valves air cleaner
- 7. Reed valves
- 8. Power valve
- 9. Vacuum accelerating pump
- 10. Automatic cold starting device
- 11. EGR valve
- 12. Vacuum tapping line for EGR valve control thermovalve
- **13.** Vacuum tapping line for delay valve and thermovalve 23
- 14. Gulp valve
- 15. Gulp valve electrovalve
- 16. Exhaust gas line from EGR to intake manifold
- 17. Gulp valve line to intake manifold
- 18. Delay valve for advance capsule
- 19. Gulp valve electrovalve vacuum line
- 20. Heated water line for thermovalves and cold starting device
- 21. Gulp valve control thermovalve (Blue)
- 22. Advance capsule control thermovalve (Black)
- 23. EGR valve control thermovalve (Red)
- 24. Air accelerating pump control thermovalve (Green)
- 25. Power valve control thermovalve (Yellow)
- **26.** Vacuum tapping line for thermovalves 16 25 26
- 27. Two-way exhaust manifold
- 28. Catalytic converter
- 29. Air distribution line
- 30. Air pump




# **COOLING SYSTEM**

#### **Coolant Circuit**

Every 500 miles or weekly - Check the coolant level in system expansion tank, with cold engine: the level must always be abt. 7 cm  $(2^{3}/_{4} in)$  above the MIN mark on tank.

When engine is very hot the level might rise noticeably: this could also happen immediately after stopping the engine.

Should the coolant level drop below the tank MIN mark, top up by removing



expansion tank cap and pouring in coolant, seeing that its level is as specified.

Warning: Do not remove radiator or expansion tank caps on a hot engine to avoid possibly scorching your hands; wait until engine has cooled down. Do not top up a hot engine with cold water.

FILIAIT

Should more than 2 consecutive top-ups be required at short intervals, or after limited

mileages (500 miles), the system needs checking. This applies also when water temperature gage pointer stays on the red sector (see page 6).

To drain cooling system, move lever **D** to the left (see page 12), open the cocks on radiator lower side and on cylinder block, and disconnect expansion tank hose.


To fill the system:

- Connect expansion tank hose, close radiator cock and remove plug A.
- Pour in water slowly through radiator filler port until water overflows, then refill the expansion tank.
- Refit radiator and expansion tank caps and plug A then run the engine so as to favor a thorough mixing of the fluid in the system.

- Stop the engine, slacken plug A, wait for a proper system bleeding and refit the plug.
- With engine cold check the level in expansion tank and, if nec. top up.

#### Antifreeze Mixture

The cooling system is filled with an antifreeze mixture effective down to -35 °C (-32 °F). In case of coolant change or topping-up FIAT recommends the use of a 50-50 mixture of water and Paraflu 11 fluid (or equivalent), which allows the use of hard or chlorinated water and incorporates



oxidation, corrosion, foam and scale inhibiting properties and is effective down to  $-35\,^{\circ}\text{C}$  ( $-32\,^{\circ}\text{F}$ ). See Fill-up Data Table.

This mixture shall subsequently be replaced after **45 000 miles** or every **two years**, whichever occurs first thus reducing the need for any servicing action on the cooling system.

When this mixture is used, plain water may be added only in emergencies (sudden heavy coolant losses).



As soon as possible repair the fault and refill the system with the recommended coolant.

### BRAKES

Brake system with front and rear independent circuits.



If pedal free travel has become excessive, if braking unbalance on one wheel is appreciable


or if pedal sponginess is felt with consequent reduced brake effectiveness, a complete inspection of the system is needed.

#### Fluid Reservoir

The «Low Brake Fluid Level» indicator (see page 7), controlled by a float and switch assembly on brake fluid reservoir, warns the driver of a sudden drop in brake fluid.

A - Front brake fluid section

B - Rear brake fluid section



**Every 15 000 miles** - Top up brake fluid reservoir. Use exclusively DOT 3 Motor Vehicle Brake Fluid (conforming to F.M.V.S.S. No. 116). Avoid using any other type of fluid which would damage the special rubber parts in the system.

# Front Brakes

**Every 7 500 miles** - Check that brake linings are not worn down to less than 1.5 mm (.06 in). Replace if required.

#### Lines and Fittings

**Every 15 000 miles -** Check hoses and fittings for leakages and tightness.

#### Bleeding



Bleeding is a delicate operation requiring the necessary know-how and should only be needed air has entered either one or

when air has entered either one or both brake circuits (line disconnection,

fluid drainage, etc.). This is indicated through pedal sponginess and reduced braking effectiveness.


#### Hand Brake

the appropriate tensioner (200 files)

15 000 miles or sooner if hand lever stroke is excessively long, pull up the lever three notches and adjust through

the appropriate tensioner (see figure below).

Then release the lever and check that the wheels are not locked.



# **POWER TRAIN**

#### Clutch

The clutch is mechanically controlled, with automatic wear take up and no pedal free travel.

# Every 15 000 miles




Check pedal height and adjust if necessary.

After repeated adjustments, check clutch facings for excessive wear: replace if required.

# Manual Transmission Oil

# Every 30 000 miles

Renew oil. Let drip thoroughly from plug  ${\bf B}$  before refilling. The correct level is up to the opening of filler plug  ${\bf A}$ .



# Automatic Transmission (Where fitted)



If defective transmission operation is detected contact your nearest FIAT Dealer.

#### Every 3 000 miles

Check the fluid level. Correct level is between the MIN and MAX marks on dipstick A.

Before checking the fluid level drive about 6 miles to reach normal operating temperature, stop the car on level ground but keep the engine


B

running at idling speed, and move the gear selector lever to **P** or **N**.

If necessary, top up to the MAX mark through filler **B** using **Fiat GI/A** or equivalent grade of automatic transmission fluid. Do not overfill.

The utmost care should be taken to ensure that both the containers and the funnel used for topping up are absolutely clean.

Following emergency topping-up after a sudden leak, owners are recommended to contact the nearest FIAT Dealer for a general inspection of the transmission.



**Every 30 000 miles or two years** - Renew the fluid with a warm transmission. If the fluid is found to be heavily soiled, also renew the filter in the value assembly together with the

the valve assembly, together with the associated seal.

To renew the fuild remove plug A.

To renew the filter remove sump B.

# Axle Oil

# Every 30 000 miles

Renew oil after thorough draining through plug **B**. The correct level is up to the opening of filler plug **A**.



# SUSPENSION AND STEERING

# Front Suspension Steering Articulation Boots and Caps

**Every 15 000 miles** or whenever underbody inspections are carried out, check the condition of ball joint rubber caps and steering gear rack rubber boots.



If they are damaged, replace. The new caps should be packed with **grassofiat MR 3** prior

to their installation.


At the same time inspect ball joints for excessive play. If evidence of looseness exists, replace the ball joint.

Proper joint maintenance is essential for car safety.

# Front and Rear Suspensions



Check rubber mounts for proper efficiency.



### Front Wheel Bearings

Every 30 000 miles - Check bearings



for play and adequate lubrication. Adjust and lubricate with **grassofiat MR 3**, if needed.

### **TIRES**

**Every 500 miles or weekly** - Check pressure with a gage not forgetting the spare wheel (see page 56 for pressures).

Make sure pressure is exactly the same in each pair of tires. In hot climates, do not reduce pressure as this would only increase tire temperature.

# MISCELLANEA

# Windshield Washer

Every 7 500 miles approximately Check level in the bottle located in left headlamp compartment.

In case of incorrect jet aiming: Clean the jet squirt hole accurately (by a needle).

Check also electric pump terminals.


To re-aim jets: Turn the complete body with a screwdriver and then the lateral pin so as to direct the water squirt to top of wiper sweep arc.

### Windshield Wiper

# Every 7 500 miles approximately

Check for proper efficiency.

To remove a wiper blade, tilt out the arm, free blade mount **A** from its lock dowel **B** on arm and extract the blade upwards.



**Note** - When adjusting wiper arms position on windshield ensure that the distance from windshield base to wiper arm fulcrum is:

driver's side = 55 to 75 mm passenger's side = 70 to 90 mm



# BODY

# Every 15 000 miles

Lubricate the following items as required using the recommended products:

Door lock cylinders with **graphite powder**.

Door locks through the specially provided hole (near lock) blanked by a plastic plug, door hinges and limiter, and front seat reclinable backrest control with **engine oil**. Window venti-pane joints and hinges with **glycerine** (2-door version).

Trunk lids and engine hood catches and hinges with **petroleum jelly**. Seat guide rails with **grassofiat Jota 1**.

# Tool Kit

The tool box contains:

Wrench, socket, spark plugs
Wrench, double end, 8 x 10 mm
Wrench, double end, 13 x 17 mm
Screwdriver, double-tipped
Punch, straight

Wrench, wheel bolts The jack is stored in trunk, on righthand side.

#### **Exterior Body Care**

Wash the bodywork frequently with cold or lukewarm water. Sponge down using a good quality car shampoo - **Deterlux** or equivalent. Never use household soap or detergent, otherwise the paintwork may be adversely affected.

If a hose is used avoid directing it at full force against the body. Rinse thoroughly and dry off with a clean chamois leather.

Do not wash your car in the sunshine, especially in hot climates or when the hood is still hot.

When cleaning the windshield raise the wipers clear, and do not force them sideways.

An occasional light polish with an approved silicone car polish will give

the paintwork extra protection. Also remove any stain promptly.

Grease and tar should be removed using a clean and soft kerosene- or gasoline-moistened cloth. Subsequently, apply a fresh coat of polish.

To clean the windows use a good quality spray type window polish - **DP 1** or equivalent - and wipe dry with water-absorbing paper.

Chromium-plate and any other bright decorative metal parts are best cleaned with either cold or tepid water, or any reputable make of car chrome cleaner.

To preserve the rubber seals of doors, hood and trunks use silicone grease. This will also prevent squeaking, particularly during the cold season.

# Interior Body Care

Dust the interior, preferably using a vacuum cleaner.

To remove grease spots from cloth lining use a good brand of stain remover (petroleum ether or light gasoline) apply talc liberally, allow to soak and brush off.

To remove dirt from the seats or any other imitation leather-lined part use a damp sponge and a neutral or bland soap. Subsequently, rinse with a clean damp sponge and dry off using chamois leather.

Textile fiber mats should be cleaned using a moistened cloth with good quality detergent.

Rubber mats or floor lining should be washed with a damp sponge and neutral detergent or water and soap.

# PROLONGED INACTIVITY

If the car is to remain inactive over long periods it is advisable to carry out the following operations:

- Store the car in a covered, dry and ventilated place.
- Ensure that the handbrake is released.
- Do not empty the cooling system: in cold climates, if necessary, replace the coolant with a reliable high grade anti-freeze mixture.
- Check the tire inflation pressures periodically.
- Re-charge the battery about every six weeks.
- Switch off any electrical loads and remove the ignition key.
- Protect the finish with a coat of good silicone wax.
- Coat all bright metal parts with a reputable make of car chrome preservant.

- Remove the wiper blades to prevent the rubber from distorting.
- Protect the car using a non-plastics car cover.

If the car is to be left in the open spray the underside and the entire engine compartment with an approved engine preservant, **PROT V** or equivalent. Do not spray a hot engine.

Before starting a sprayed engine open the hood and wait for at least ten minutes.

Prior to using the car following a prolonged period of inactivity perform the following operations:

- Remove the chrome preservant from all bright metal parts.
- Wash the car.
- Renew the engine oil.
- Recharge the battery.
- Refit the wiper blades.
- Check the tire inflation pressures (including that of the spare wheel).

# **ELECTRICAL SYSTEM**

#### Battery

Located in trunk.

**Every 3 000 miles or monthly** - With battery at rest and cold, check the electrolyte level.

In hot climates, check the level more often.

When liquid additions are needed, add distilled water (battery cold), never electrolyte fluid (which contains sulphuric acid) as only water evaporates from the battery in service, **never** the acid.



**WARNING** - The battery contains sulphuric acid. Avoid contact with skin, eyes or clothing.

External antidote: Flush with water.

Internal antidote: Drink large quantities of water or milk.

Follow with milk of magnesia, beaten egg or veg. oil.

Call physician immediately.

Eyes: Flush with water for 15 minutes and get prompt medical attention.

Batteries produce explosive gases. Keep sparks, flame, cigarettes away.

Ventilate when charging or using in enclosed space.

Always shield eyes when working near batteries.


Keep out of reach of children.

# Every 3 000 miles

Check posts and clamps for tightness and cleanliness.

Except in particular service conditions the battery does not require any periodical recharge.

As your car is fitted with electronic devices never run the engine - even for a very short while - with battery disconnected from the alternator or wrongly connected (positive ground) otherwise serious damage will result.




#### Fuses

Nine 8-Amp. and three 16-Amp. fuses in a box under dash, driver's side, and one 8-Amp. fuse in separate holder.

Before replacing a blown fuse trace the cause and remedy accordingly.

# Unprotected Circuits

Alternator, ignition, starting, battery charge indicator, idle stop solenoid, Gulp valve electrovalve (off at starting), starting motor relay coil (automatic transmission), power windows relay coil (where fitted).



# Protected Circuits

**A** (8 Amps)

Turn signal lamps and indicator Stop lamps Oil pressure gage and insufficient pressure indicator

Engine coolant temperature gage Fuel gage, with reserve indicator

Engine tachometer

Low brake fluid level and hand brake ON indicator

Back-up lamps

Fast idle electrovalve

Fasten belts indicator and relay for

buzzer

Delay circuit for fasten seat belts indicator and buzzer

Selected gear indicator light

**B** (8 Amps)

Windshield wiper
Heater fan motor
Windshield washer pump
Windshield wiper sweep rate rheostat

C (8 Amps) Left headlight high beams High beam indicator **D** (8 Amps)
Right headlight high beams

E (8 Amps)
Left headlight low beam

F (8 Amps)
Right headlight low beam

G (8 Amps)
Front right parking lamp
Rear left tail lamp
Front right/rear left side marker lamps
License plate lamp (right)

H (8 Amps)
Front left parking lamp
Parking and tail lamps indicator
Rear right tail lamp
Front left/rear right side marker lamps
License plate lamp (left)
Cigar lighter housing indicator
Trunk light
Instrument cluster lights
Ideogram illumination optical fibers


light source Vehicular hazard warning signal switch light Quartz crystal clock
Courtesy light
Hazard warning flasher and indicator
Inspection lamp receptacle
Remove key and fasten belts buzzer


L (16 Amps)
Horns
Engine fan motor

M (16 Amps)
Power window motor (Left - if fitted)

N (16 Amps)
Power window motor (Right - if fitted)

In separate holder Cigar lighter





# Lights

#### Headlights

# **Alignment**

For aiming the headlights, screw **B** (vertically) and **C** (horizontally) are readily accessible after removing retaining ring **G**.

#### Removal

Turn off screw **E** and remove retaining ring **G**. Slacken 4 screws **D** and, by turning counterclockwise remove headlight unit **L**. Then pull off terminal socket **I**.


**Caution:** Replace blown bulbs exclusively with bulbs of the same type and wattage. Weaker bulbs will diminish visibility whereas stronger bulbs will draw a greater amount of current and overwork the alternator, resulting in progressive battery discharge. For bulb specifications see page 47.

#### Installation

Center headlight unit **L** on body by aligning locating dowel **H** with its seat. Turn the unit clockwise and tighten screws **D**. Refit retaining ring **G** by tightening screw **E** in hole **F**.

# Front Parking and Turn Signal Lamps

- A Lens mounting screws
- B Lens
- C Bayonet-coupled bulb, double filament
- **D** Positioning tabs



# Rear Turn Signal, Stop and Back-up Lamps

The bulbs are accessible from inside trunk after removing panel **A**.

To remove the panel free it from the arrowed lugs.

The bulbe are of the bayonet type.


- B Turn signal light
- C Stop light
- **D** Tail light
- E Back up light


# Side Marker Lamps


The rear bulb holders are accessible from inside the trunk.

To remove the bulb, disconnect bulb holder  ${\bf A}$  from seat  ${\bf B}$  by turning counterclockwise.

Bulb C is of the plug-in type.







Front bulbs are accessible from inside fenders.

To remove or refit follow the procedure given for the rear bulbs.

# Courtesy Lamp


- A Spring plates (two) unit mounting
- **B** Switch
- C Bulb, pressure mounted
- D Lens and body unit


# License Plate Lamps

To withdraw bulb holder remove retaining nuts from inside the trunk.

- A Body retaining screws
- **B** Body and lens
- C Bulb holder
- **D** Bayonet-coupled bulb
- E Gasket







# SPECIFICATIONS

# **ENGINE**

Type	132 C3.040
Number of cylinders, in line	4
Bore and stroke	84 x 90 mm
	(3.31 x 3.54 in.)
Total piston displacement.	1995 cc
	(121.74 cu. in.)
Compression ratio	8.1 to 1
Maximum power (SAE net)	80 HP
at	5 000 rpm

#### Valve Gear

O. H. V.			
Twin O. I	H. camshafts driven	by	toothed
timing I	pelt with tensioner.		
Intake	Opens: B.T.D.C.		5
illake )	Opens: B.T.D.C. Closes: A.B.D.C.		53
Exhauet	Opens: B.B.D.C.		539

 $\begin{array}{lll} \text{Exhaust} & \left\{ \begin{array}{ll} \text{Opens: B.B.D.C.} & 53^{\circ} \\ \text{Closes: A.T.D.C.} & 5^{\circ} \end{array} \right. \\ \text{Tappet clearance adjust-} \\ & \text{ment, for valve timing .80 mm (.031 in.)} \\ \end{array}$ 

Final tappet operation clearance adjust-

ment, **cold engine:** Intake  $.45\pm.04\,\mathrm{mm}$  (.0177 $\pm.0016\,\mathrm{in.}$ ) Exhaust  $.50\pm.04\,\mathrm{mm}$  (.0196 $\pm.0016\,\mathrm{in.}$ )

### Lubrication System

Forced circulation by gear pump. Pressure limiter valve on delivery circuit. Full-flow cartridge oil filter.

#### Fuel System

Vertical dual-barrel downdraft WEBER 28/32 ADHA 7/180 (ADHA 8/180 for cars fitted with automatic transmission) carburetor with differential opening of the secondary throttle, automatic butterfly valve choke. Idle stop device.

Enrichment system consisting of mechanical accelerating pump, vacuum assisted accelerating pump and power valve.

Carburetor feed by mechanical pump.

Fuel filter in feed line from fuel pump to carburetor.

Paper cartridge air cleaner with silencer.

# **Emission Control Systems**

Engine feed system provided with fuel recirculation (closed circuit) and evaporative emission control system.

Crankcase emission control (CEC) system (closed circuit) by recirculation of blow-by gases and oil vapors.

Exhaust emission control system (reduces air pollution from the exhaust by gas recirculation and post-combustion process) separate from the CEC system.

#### Cooling System

Radiator and translucent expansion tank. Water circulated by centrifugal pump. Thermostat with controlled by-pass on cylinder head water outlet duct. Four-blade fan driven by electric motor controlled by thermostatic switch on radiator: cut-in temperature about 90° C

### Ignition System

standard	type	resistor	type
CHAMPION	N9 Y	CHAMPION or RN1 OY	RN9 Y
AC DELCO	42-XLS	AC DELCO or R43 - XLS	
MARELLI	CW 7LP	MARELLI or CW 67 LP	
FIAT	1L4J	FIAT	1L4JR
BOSCH	W 7D	BOSCH or WR7D2	WR7D
Thread size		14 x	1.25 mm
Gap			
-4		7 / 000	007: 1

standard type .6 to .7 mm (.023-.027 in.)resistor type .7 to .8 mm (.027-.031 in.)

# **POWER TRAIN**

#### Clutch

single plate, dry, with disk spring, mechanically controlled, automatic wear take up no pedal free travel.

# Manual Transmission

Five forward speeds (all synchronized) and reverse.

Gear ratios to 1:

1st	2nd	3rd	4th	5th	Reverse	
3.612	2.045	1.357	1	.830	3.244	

# **Automatic Transmission**

(Optional Extra)

G. M. hydraulic torque converter-gearbox unit.

Multiplication range . . . 2.4:1 to 1:1

Transmission ratios:

# Propeller Shaft

Tubular propeller shaft in two sections, with rubber mounted central pillow block. Front section connected to transmission by flexible joint and slip yoke. The second section is connected to the first and to rear axle by universal joints.

### Rear Axle

Final drive hypoid gear ratio: 10/39
— with automatic transmission 12/43

# **BRAKES**

### Service

Hydraulically operated by pedal through vacuum servo and tandem master cylinder.

Front: disk type, with floating caliper and one cylinder to each wheel.

Rear: self-centering, expanding-shoe drum type, with one cylinder to each wheel. Independent front and rear circuits.

Proportioning valve in rear circuit for car load and deceleration rate variation compensations.

Device for automatic wear take-up.

### Parking

Mechanical, operating on rear brake.

#### SUSPENSIONS

#### Front

Independent wheels, by swinging arms, with coil springs and hydraulic, double-acting telescopic shock absorbers. Stabilizer bar. Sealed-for-life articulations.

#### Rear

By rigid axle anchored to body through 5 reaction rods - 4 longitudinal and 1 transversal. Coil springs, hydraulic doubleacting telescopic shock absorbers. Asymmetric wheel motions stabilized by elastic mounts of reaction rods.

# STEERING AND WHEELS

#### Steering

Standard . . . . . . . . . L.H.D.
Control: worm screw and roller, ratio 1/16.4.
Steering shaft in three sections, incorporating two universal joints; breakaway mount.

Independent and symmetric track rods to each wheel, with central link rod. Sealed-for-life articulations.

Hydraulic, double-acting damper on relay support.

Turning circle . . . . . 10.4 m (34 ft 2 in.) Front wheel camber, measur-

ed at rim 0 to 6 mm (.00 to .24 in.) or 30'  $\pm$  30'

The above data apply to cars laden to the equivalent of 2 adults (300 lbs) plus 130 lbs of luggage.


# Wheels and Tires

Disk wheels, ventilated, with rim size . . . . . . 5 J x 13" Radial-ply tires, size . . . 165 SR-13"

ELECTRICAL SYSTEM	Bulbs	SAE	FIAT
Voltage	Location	Standard	Std. Part No.
Alternator	Headlights (high and low beams)	« Sealed Beam »	headlight unit 4002
Continuous current rating . 55 Amps Incorporated current rectifiers. Automatic voltage regulator.	Front lamps turn signal	No. 1034 (32 cp) 1/41460/90	12V-21W Norm. 1/41481/90
Cut-in speed at starting of engine (with users off).	Rear lamps	No. 1063 (32 cp) 1/41460/90	12V-21W Norm. 1/41469/90
Battery	Rear lamps		
With grounded negative; capacity at 20-hr discharge rate 60 Amp.hr. Cold (—18°C) high-discharge	tail	No. 67 (4 cp) 1/41459/90	Norm. 1/08577/90
test current	Courtesy light		12V-5W
Starter	light source		Norm. 1/08630/90
Power rating 1.3 kW	Selected gear indicator light (aut. transmission)	_	12V-3W Norm. 1/41431/90
Direct engagement by solenoid and free- wheeling pinion.	Turn signal indicator		
Heater Fan Motor	Insufficient oil pressure indicator .		
Power rating 20 W	Fuel reserve indicator Parking and tail lamps indicator	No. 158 (2 cp)	Norm. 1/41458/90
Engine Radiator Fan Motor	Instrument cluster lights		or Norm. 1/41439/90
Power rating 110 W	Vehicular hazard warning signal in-		
Windshield Wiper Motor	Low brake fluid level and hand brake ON indicator		
Power rating 28 W	Side marker lights		
Fuses	Vehicular hazard warning signal switch light	_	12V-1.2W Norm. 1/41437/90
Nine 8-Amp, three 16-Amp fuses and one 8-Amp fuse in separate holder	Trunk lamp		12V-4W Norm. 1/41423/90

# **MAIN DIMENSIONS**

mm	520	847	1 013	1120	1 250	1 320	1 350	1 613	2 281	4141
in.	20.5	33.4	39.9	44	49.2	5 <b>2</b>	53.2	63.5	89.7	163



Overall height is measured with unladen car. Trunk volume: 180 cu. dm (6.4 cu. ft).

# **PERFORMANCE**

# Speeds

Maximum speeds after break-in, fully laden

				Manual T.	Auto-Transm
1st ç	gear			28	47
2nd	gear			50	76
3rd g	gear			76	103
4th g	gear			104	
5th g	gear,	٥١	/er	105	

# Gradeability

Maximum grades climbable, fully laden

		%	%
1st gear .		48	48
2nd gear		29	30
3rd gear .		17	20
4th gear .		12	
5th gear .		9	

# **WEIGHTS**

Curb weight { manual . . . 2 360 lbs automatic . . . 2 400 lbs

# 2000 Spider

Fuel Injection System

This section dealts with the model featuring fuel injection system.

Refer to the previous section for any information not contained herein.

# IDENTIFICATION DATA

Type 132.C3.031 and Engine Identification Number - Punched on crankcase, flywheel side.


E.P.A. and California Regulations Conformity Tag - Air pollution control specifications for correct engine tune up and adjustments, located in engine compartment, on cowl.


# **EXHAUST GAS SENSOR** INDICATOR (red)


Lights up:


- Every 30 000 miles to warn owner of need to replace exhaust gas sensor (Lambda probe);
- On starting; it should go out when engine is started.











# STARTING THE ENGINE

# Cold Starts With Manual Transmission

- Move gearshift lever to neutral.
- Depress clutch pedal, especially in cold climates.
- Insert and turn ignition key clockwise to the stop, that is position AVV. As soon as engine is started release key which will snap back to position MAR.

Should the engine fail to start return ignition key back to **ST** position and repeat starting attempt.

- Do not step on accelerator pedal until the engine is running smoothly.
- Avoid sudden acceleration when engine is cold.

Do not continue with repeated starting attempts. If the engine fails to start or stalls at idling have the fuel and ignition systems checked as soon as possible.

# **Cold Starts With Automatic Transmission**

Move the selector lever to **N** or **P**. Engine starting is not possible with the selector lever in any other position.

Then proceed according to manual transmission instructions.

#### **Hot Starts**

For vehicles with manual and automatic transmission turn ignition key without touching accelerator pedal.

# MAINTENANCE (see also page 23)

# GENERAL MAINTENANCE SCHEDULE

This schedule and the SPECIAL MAINTENANCE SCHEDULE on the next page list all maintenance operations to be carried out on this type of car and the relevant page references.


■ We recommend that all operations so marked be entrusted to the Fiat service network

OPERATIONS	See page	Every 15 000 miles	Every 30 000 miles	Every 45 000 miles
■ Valve clearance: Check and adjust if necessary	26	•	•	•
Air cleaner: Renew filtering element	58	• *	•	• *
■ Spark plugs: Change	58	• *	•	• *
Alternator and water pump drive belt: Check tension and state of wear: Adjust and/or renew as necessary	59	• *	•	• *
Oxygen sensor (Lambda probe): Renew	63		•	
■ Brakes: Check state of wear of seals, lines and check hand brake efficiency, renew or adjust as necessary	36	•	•	•
■ Suspensions, steering and drive line: Check components	39	•	•	•
■ Wheel bearings: Check Iubrication	39		•	
■ Clutch: Check pedal height and adjust if necessary	37	•	•	•
■ Transmission (manual and automatic) and differential: Change oil	37-38		•	
Body: Lubricate door locks and hinges	40	•	•	•


<sup>\*</sup> These operations are not obligatory but only recommended whenever the car is used frequently in abnormal traffic conditions or on sandy and dusty roads.

# SPECIAL MAINTENANCE

OPERATIONS	See page	Every 500 miles (or weekly)	Every 5 Every 7 500 miles miles	
Engine oil: Check level	26	•		
Engine oil and filter: Change	26		•	
Cooling system: Check coolant level	35	•		
Brakes: Check brake pads and front discs	36		•	
Automatic transmission (where fitted): Check oil level	38			
Tyres: Check pressure	39	•		
Battery: Check electrolyte level, terminals and clamps	42			







### Air Cleaner

Every 30 000 miles (\*): Change filtering element. To gain access to filtering element A undo fasteners C using a screwdriver and remove cover B.

Change the filtering element, refit cover and secure with fasteners C.

Reinstall fasteners by pressing on curved section.

# Spark Plugs

**Every 30 000 miles** (\*): Change spark plugs. To disassemble 'spark plugs, withdraw terminals A and back off using a suita-

ble wrench.

New spark plugs must be of the type specified (see page 68); if their thermal rating is incorrect engine malfunction and/or failure may occur.

(\*) It is recommended that air cleaner and spark plugs be replaced every 15 000 miles if the vehicle is frequently driven in heavy traffic conditions or sandy or dusty areas.



# Alternator and Water Pump **Drive Belt**

Every 30 000 miles (\*): Check belt for wear and if necessary renew. Also check belt tension and adjust if necessary.

Belt sag should be 1 to 1.5 cm (1/3)to 1/2 in.) when firm thumb pressure is applied. To adjust tension of belt


driving water pump A and alternator B, slacken nuts C and D and move alternator outwards and then retighten with new nuts.

Do not exceed the tension since this would result in abnormal stress on the bearings.

- For vehicles fitted with manual transmission, engage top gear and move vehicle until cylinder no. 1 is in compression phase and the mark on the crankshaft pulley is aligned with the fixed timing mark A indicating 10° B.T.D.C.

(\*) It is recommended that these operations be carried out every 15,000 miles if the vehicle is frequently driven in heavy traffic conditions or in sandy and dusty areas.


Ignition timing:  $A = 10^{\circ} (Adv.); B = 5^{\circ} (Adv.); C = 0^{\circ} (TDC)$ 



# **Ignition Timing**

Spark advance is set in the factory and not further adjustment is required during the life of the vehicle.

Ignition timing must be checked only if the ignition distributor is removed. To adjust proceed as follows:



For vehicles fitted with automatic transmission use a suitable wrench to adjust the nut **D** securing crankshaft pulley until above conditions are obtained.

 Remove distributor cap and turn shaft manually until rotor is positioned against contact for firing of cylinder no. 1.

Without moving distributor shaft, insert distributor in its seat and secure. Connect leads going to coil, install cap and check that the leads are correctly connected to spark plugs.

Connect the rev counter and the stroboscopic lamp to the engine using spark plug lead for cylinder no. 1.

- Start engine and check ignition timing with the stroboscopic lamp. Ignition timing should be 10° B.T.D.C. at 800 to 850 rpm for vehicles with manual transmission and 10° B.T.D.C. at 700 to 750 rpm for vehicles with automatic transmission.
- If distributor calibration is not correct, slacken manually and rotate until correct calibration is obtained, then tighten it.

If distributor removal is not required, proceed from this point.

# EMISSION CONTROL SYSTEM

Vehicle emissions are controlled by various devices that make up the crankcase emission control system, the exhaust emission control system and the fuel evaporative emission control system.

Any modification of the emission control systems is subject to federal laws and regulations and may incur penalties.

60


38119

# Crankcase Emission Control System

This is a closed system designed to prevent any emission of blow-by gases and oil vapours into the atmosphere.

These gases and vapours are piped to an orifice downstream of the throttle and are then drawn into the engine in any rpm condition.

- 1. Emission feedback port
- 2. Throttle valve
- 3. Flame trap
- 4. Intake manifold
- 5. Sump-to-air cleaner line
- 6. Cyclone liquid/vapor separator
- 7. Oil drain line into sump



61

# Fuel Evaporative Emission Control System

The fuel evaporative emission control system is designed to prevent air pollution caused by evaporative losses from the fuel system.

This is accomplished by a proper system which prevents the release into the atmosphere of fuel vapors from the fuel tank.


The fuel vapors from the fuel tank flow into the activated charcoal carbon canister where they are absorbed and stored when the engine is not operating.

When the engine is running, the fuel vapors retained in carbon canister are purged through a line which conveys them to intake manifold.

The system consists essentially of:

- Sealed filler cap.
- Limited-filling tank.
- Vapour-liquid separator.
- Two-way valve.
- Vapour vent line.
- Carbon canister.
- Purge line.

1. Beneza druit regler (auvich) 2. Thermofisher lit haltstat 3. Lufturgennene



Fuel pressure regulator - 2. Cold start solenoid injector - 3. Solenoid injectors - 4. Activated carbon canister - 5. Two-way valve - 6. Fuel tank vapor vent line - 7. Fuel return line - 8. Fuel delivery line - 9. Fuel filter - 10. Electric fuel pump - 11. Sealed filler cap - 12. Vapour-liquid separator.

# Fuel Injection System General

This is an electronically controlled intermittent low pressure injection system.

The fuel is injected upstream of the intake valves by means of solenoid injectors supplied at constant pressure. Flow is controlled by means of variation in the opening time of the injectors.

The main factor controlling flow is the direct measurement of drawn air by a special sending unit which transmits the most important information for fuel metering to the electronic control unit.

The system is also provided with a certain number of measuring sensors which provide the electronic control unit with the information required to optimize the composition of the mixture in all engine operating conditions.

# Exhaust Gas Emission Control System

For the control of exhaust gas emissions, the injection system is fitted with


an oxygen sensor (Lambda probe) which measures the oxygen content of the exhaust gases and transmits any adjustment of the air-fuel mixture to the control unit. It is thus possible with the aid of a catalytic converter fitted to the exhaust pipe, to reduce to a minimum the harmful residues contained in the exhaust gases.

# Oxygen Sensor (Lambda probe)


**Every 30,000 miles:** Renew oxygen sensor. An indicator on the instrument panel lights up on completion of 30,000 miles (see page 54) signifying that the sensor must be replaced.

To renew sensor proceed as follows:

- Disconnect probe cable A.
- Back off probe B from its seat C on exhaust manifold.
- Fit new probe lubricating threaded part with anti-seize, anti-rust grease.
- Reconnect cable A.
- Press button to zero indicator.







# ELECTRONIC FUEL INJECTION DIAGRAM

# 1. Battery 🗸

**2. Dual purpose relay** - Operates electronic control unit 3 and motor driven fuel pump 17.

# 3. Electronic control unit 🧈

Receives information about oil quantity, coolant temperature and temperature of cylinder head, position of throttle valve, starting phase as well as engine rpm and injection point.

It processes this information and transmits electric pulses to the solenoid injector.

It is connected with the individual components by means of a multiple connection plug and associated connecting cables.

#### 4. Coil

In addition to its normal function, it transmits the number of engine rpm or the injection point to the control unit.

This supplies information to electronic control unit of quantity of air drawn and activates fuel supply pump.

# 6. Supplementary air valve /

Supplies extra air during engine heating stage, depending on temperature level.

# 7. Throttle switch

control unit.

Signals idle and full load to electronic

# 8. Temperature sensor

Signals coolant temperature at the cylinder head outlet.

# haltstartventil 9. Cold starting solenoid injector

During starting in low temperatures, injects extra fuel into intake line.

# Temperaturable für 9

Inject fuel in intake port of cylinders.

# 11 Delay thermal switch

This automatically controls injection of cold starting solenoid injector.

# 12. Fuel pressure regulator

Keeps fuel pressure constant in fuel lines.

# 13. Fuel delivery line

# 14. Excess fuel exhaust line

# 15. Ignition switch

### 16. Fuel filter

Is fitted on fuel supply line for fuel filtering.

#### 17. Motor driven pump

Delivers a constant supply of fuel to solenoid injector.

#### 18. Fuel tank

### 19. Oxygen sensor (Lambda probe).

Measures the oxygen content of exhaust gases and transmits any adjustment of air-fuel mixture to control unit.

# 20. Catalytic converter

Reduces harmful residues contained in exhaust gases to a minimum.

Note: You are advised to take the following precautions:

- Never start the engine if the battery is not properly connected.
- Do not use charger with battery leads disconnected.
- Never disconnect battery leads with the engine running.
- When charging battery, disconnect clamps.
- If temperature is above 80° (special body work) disconnect electronic control unit from vehicle.
- Never remove or insert control unit harness connector with ignition switched on.
- If car is to remain out of service for some time, add 10% of engine oil to the fuel tank.

# **Idling Speed**

Any adjustment to idling speed must be carried out with a warm engine and with gearshift lever in neutral position for mechanical versions and in **D** (drive) position for automatic versions.

The engine is warm when the radiator electric cooling fan has been activated at least twice.

To adjust idle the electric fan must be

To adjust, turn bypass crew A.



Idling speed is 850  $\pm$  50 rpm for manual transmission and 750  $\pm$  50 rpm for automatic transmission.


# **CO Regulation**

1. The CO is set in the factory and no further adjustment is necessary.

In the case of replacement of injection system components check CO at idle as follows:

- Adjustment of mixture metering must be carried out after idle speed adjustment as described above.
- Remove plug A on exhaust line upstream of the catalytic silencer and connect CO indicator probe with F.S.D. of not more than 5%.
- Disconnect supply cable B of probe
   C and check that terminals are not grounded.









- Remove seal on bypass screw  ${f D}$  of air flowmeter and turn the screw until a  ${f CO}$  concentration of 0.7  $\pm$  0.2% is obtained.
- Connect to ground cable E of oxygen sensor connected to the electronic control unit and check that in these conditions the CO concentration is at least 1.5%.
- Reconnect the oxygen sensor and check that the CO concentration falls to within 0.3 to 0.6%.
- Reapply the seal to the air flowmeter bypass screw.

# WARNING

# Fuel Refilling

Strictly adhere to the label on instrument panel and on filler cap.

# UNLEADED FUEL ONLY

Leaded fuel will damage the catalytic converter beyond repair.

To prevent this happening, the fuel filler is designed in such a way as to allow refilling only from pumps carrying unleaded fuel.

# SPECIFICATION

# **ENGINE**

Type	132 C3 031
Compression ratio	82 to 1
Maximum power (SAE net)	102 HP
— At	5 500 rpm

# Fuel System

Electronically controlled fuel injection.

4 injectors, one per cylinder plus one auxiliary injector for cold starting, all supplied at constant pressure.

Gasoline flow governed by variation in opening time of injectors.

An air measuring instrument is used for flow variation.

Electric sensors optimise the mixture in all engine operating conditions, supplying information to the electronic control unit.

Air cleaner installed before air measuring instrument with paper cartridge.

# Ignition System

Electronic, with inductive discharge ignition distributor.

Automatic advance  $18^{\circ} \pm 2^{\circ}$ . Spark plugs: Champion RN9Y Thread size:  $14 \times 1.25$  mm

Gap: 0.7 to 0.8 mm (0.027 to 0.031 in)

# ELECTRICAL SYSTEM

# **Protected Circuits**

**A** (8 amps)

- 30 000 mile pick-up and indicator.

In separate housing (16 amps).

Motor driven fuel pump.

- Supplementary air solenoid valve.

# **Unprotected Circuits**

Generator, starting and associated relay, ignition, activation of relay for high beams battery charge indicator, radio receiver (where fitted), electronic injection system excluding two components protected by fuse 14.

#### Bulbs

30 000 mile indicator (exhaust gas sensor) bulb: 12 V - 3 W.

# **WEIGHTS**

Weight in running order (with fuel, spare wheel tools, and accessories):
Manual transmission . 2 360 lbs.
Automatic transmission . 2 400 lbs.
Vehicle load capacity (total 430 lbs.):
Two adults (300 lbs.) plus 130 lbs. of luggage.

Gross weight (fully laden):

Manual transmission . . 2 790 lbs. (\*)
Automatic transmission . 2 830 lbs. (\*)
Seat capacity . . . . 2 persons
Passenger distribution . 2 in front

(\*) Add 80 lbs with air conditioner.

#### **PERFORMANCE**

# Speeds

Maximum speeds after break-in, fully laden

	Manual T.	Auto-Transm.
1st gear	29	47
2nd gear	50	76
3rd gear	76	104
4th gear	104	
5th gear, over	107	

# Gradeability

Maximum grades climbable, fully laden

		%	%
1st gear		53	45
2nd gear		26	25
3rd gear		16	17
4th gear		11	
5th gear		9,5	

# FILL-UP DATA

	dm³ It	kg	U.S. units		
Fuel tank	43	_	11.4 Gals	Unleaded gasoline with octane rating of at least 91 (Research Method)  Antifreeze mixture (¹)  Low-ash content detergent oils-API Service SE to MIL-L-46152 and above the CCMC European Sequence. See Table below  SAE 80W/90 oil containing special antiwear additives A.T.F Dexron type fluid  SAE 80W/90 EP oil  DOT 3 Motor Vehicle Brake Fluid to F.M.V.S.S. No. 116	
Radiator, cylinder jackets and heating system	8	_	81/2 Qts		
Engine sump and filter (2) .	4.125	3.750	4 <sup>1</sup> / <sub>4</sub> Qts		
Manual transmission	1.65	1.50	13/4 Qts		
Automatic transmission	2.80	2.5	3 Qts		
Rear axle	1.30 .215	1.20 .195	1 <sup>2</sup> / <sub>5</sub> Ots <sup>2</sup> / <sub>5</sub> Pt		
Hydraulic brake circuits	.380	.380	1/ <sub>3</sub> Pt		
	Temperature			Solvent in bottle Pure water plus	
Windshield washer	above 0° C (32° F) down to —10° C (14° F) below —10° C (14° F)			3% high quality 50% windshield 100% washer solvent	

Out	door temperature	oliofiat Single-grade	oliofiat Multigrade	
Minimur	n below —15°C (5°F)	<b>VS</b> + <b>10 W</b> SAE 10 W		
Minimur (5° F to	n between —15° and 0° C 32° F)	VS+ 20 W SAE 20 W		
Minimum above 0°C	Max, up to 35°C (95°F)	<b>VS</b> + <b>30</b> SAE 30	<b>VS</b> + <b>15 W</b> / <b>40</b> SAE 15 W/40	
(32° F)	Max. over 35° C (95° F)	VS+ 40 SAE 40		

Do not mix oils of different brands or grades.

- $(^1)$  The system is filled with a 50-50 mixture of water and **Paraflu 11** fluid (see Page 35).
- $(^2)$  Total capacity of sump, filter and lines is 4.35 kg  $(5^1/_5\,\mathrm{Ots}).$  The amount indicated is the requirement for periodical oil changes.

# Tire Pressure

Front and rear . . . . . . 28 psi

Note: To obtain the required safety in car performance strictly adhere to the pressure rating given. Tire inflation pressure should be checked with cold tires.

## **INDEX**

General			
	page	Page	Page
Identification data	2 2	Coolant circuit       35       Suspension articulations	26 27 39
Operation		Engine lubrication	
Automatic transmission  Doors  Driving the car  Fold-away top Instruments and controls  Jacking-up and towing	10 17 14 5	Engine oil filter	34 39 39
Parking	18	General maintenance schedule 24 Hand parking brake	
Seats Seat belts Starting the car Starting the engine Ventilation and heating Wheel changing	11 16 16 12	Headlights	51 49 53 52 52 50
Maintenance		Power train	
Air cleaner Antifreeze Axle oil Battery	35 38	Spark plugs	
Body care	0-41 36	Steering articulations	53
Brake fluid reservoir Brake system bleeding Carburetor Clutch	36 29	Important - All conversions are in U.S. units. They are given merely for Owners' of venience and, though the closest approximation is sought, are normally rounded for practical reasons. It must therefore be understood that in case of any or crepancy the metric units are the only valid reference.	off

# ACCELERATION AND PASSING ABILITY

This figure indicates passing times and distance that can be met or exceeded by this vehicle, in the situations diagrammed here. The low-speed pass assumes an initial speed of 20 mph and a limiting speed of 35 mph.

The high-speed pass assumes an initial speed of 50 mph and a limiting speed of 80 mph.

**Notice:** The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

#### TABLE 3 - Spider 2000

Low-speed	pass	360 feet;	7.5	sec.
High-speed	pass	1324 feet;	14.4	sec.

#### TABLE 4 - Spider 2000 Automatic


Low-speed pass	360 feet;	7.5	sec.
High-speed pass	1355 feet;	14.8 \$	sec.


# TABLE 5 - Spider 2000 - California Version

Low-speed pass	345 feet;	6.7 sec.
High-speed pass	1225 feet;	1.3 sec.

# TABLE 6 - Spider 2000 Automatic - California Version

Low-speed pass 350 feet; 6.9 sec. High-speed pass 1250 feet; 13.4 sec.






FILAT
Gruppo Veicoli Fiat - Assistenza Tecnica - 10134 TORINO (Italia) - Corso E. Giambone, 33
Fiat Auto S.p.A. Print No. 603.70.992 - VI - 1979 - 2000 - Printed in Italy - Stab. Grafico G. Canale & C. S.p.A.

# Advice for bodywork maintenance

Supplement to the Owner's Manual



#### **Protection from Atmospheric Agents**

FIAT has introduced a series of measures to protect the automobile from the various factors that can cause damage and corrosion.

Briefly summarized, these factors are:

- Atmospheric pollution (urban environments and industrial zones)
- Airborne salts (marine areas, particularly those with warm and humid climates)
- Seasonal and ambiental humidity conditions (use of salt on roads during the winter).

The paintwork and body shell underside can be subjected not only to the chemical action caused by the factors mentioned above, but also to the abrasive action of airborne dust and sand, mud, and loose gravel thrown up by passing cars as well as the damaging action of salt spread on the roads in winter.

FIAT's answer to this problem can be summarized as follows:

- Corrosion and abrasion resistant paints and painting systems.
- Widespread use of pre-treated and highly corrosion resistant sheet metal.
- Spraying of the underside of the floor plan, engine compartment, wheel boxes, and the various box sections with highly adhesive protective waxes.
- Adequate covering or protective spraying with setting plastic of such particularly exposed parts as the door sill panels, wing interiors, borders, and so on.
- Use of enamels with greater resistance to polluted and industrial atmospheres.

Obviously the factors we have described act in different ways in different cases, according to the environmental conditions and the use of the car. Equally obvious is the fact that the owner who cares about his car and maintains it properly can make it last longer. We would like to list a few useful hints and pieces of advice which, though obvious, often pass unobserved for that very reason. The FIAT service network will be happy to supply more details on request.

# **Body Paintwork**

Needless to say, the paintwork does not serve only an aesthetic function, but also covers and protects the metal on which it is deposited.


Therefore, any abrasion or deep scratches that expose the sheet metal should be retouched immediately to avoid pitting by rust.

This retouching should always be done with original products (see paint indentification plate).

Washing the car is the greater part of normal paint maintenance.

The frequency or washing depends not only on the frequency of use, but also on the nature of the car's surroundings: washing should be more frequent in more polluted areas, or if the car is often parked under trees which produce harmful resins.

A correct wash should be done as follows: First the car should be wet down with water at low pressure and sponged down with a light (2 - 4%) detergent solution. Rinse the sponge frequently. Rinse the car with a spray of water to carry away the loosened dirt, then dry with an air jet or chamois leather.









Be particularly careful to dry the less visible areas, such as the door frames, hood and headlight housings, where standing water can collect more easily. Similarly, avoid putting the car in a closed space immediately after washing, so that air circulation can help evaporate any trapped water.

Do not wash the car after it has been parked in the sun, or if the hood is still hot, as this could adversely affect the brilliancy of the paint.

The occasional use of a silicone car wax will give the paintwork extra protection and keep it shiny. If the paintwork becomes cloudy due to smog accumulation, a slightly abrasive light wax polish can be used.


#### **Body Underside**

The less accessible areas of the underside and frame box sections have already been treated to ensure longer duration.

Regular check-ups should be made on the car. The aim of these is to survey the soundness of the body and mechanical components, as well as to repair any damage. Particular attention should be paid during check-ups to the drainage holes in the underbody box frames and door frame undersides. These holes serve to drain any water that may accumulate while driving the car in the rain or while washing it, and so should be kept clear.

In harsh environmental conditions, periodic supplementary protective treatments to the box sections and door interiors are recommended.

These treatments must be done with special products and techniques, and so should be left to experts. It should be done at least every two years, and, in more severe cases, annually, preferably at the beginning of winter.



#### Car Interior

The maintenance of the passenger compartment is no less important than that of the exterior. The same care should be devoted to it.

Check to see that there is no standing water under the mats or floor lining, as this could cause rusting. Dust the seats and cloth parts with a brush or vacuum cleaner.

To remove grease spots use petroleum ether or light gasoline, apply talc and brush off.

To clean seats in imitation leather, use a damp sponge and a neutral or bland soap. Rinse several times with a clean damp sponge.

While cleaning perforated seat covers, be particularly careful that water does not seep through the holes to the padding.









## Windows

To ensure perfect visibility, windows should be cleaned with a good quality glass cleaner and then wiped dry. Always use a clean cloth to avoid scratching the glass.

To clean the inside of the windshield, where more obstinate grease deposits are to be found, use sulphur ether as a solvent.

The inside of the rear window can be cleaned in the same way, but particular care should be used to avoid damaging the demister wires embedded in the glass.

#### **Engine Compartment**

The engine compartment should be well washed at the end of every winter to avoid damage caused by salt on the roads.

#### Chromium Trim

Chromium parts should be coated occasionally with car chrome preservant to protect them from atmospheric agents.


## Cleaning Plastic Parts


Exterior plastic parts should be washed in the same way as the car itself. If traces of dirt remain, use special plastic cleaners, following the manufacturer's instructions. Interior plastic parts can be cleaned in the same way. Do not use paint cleaners.

## Leaving the Car in the Garage

A car left in the garage is subject to damage by humidity, which is generally greater in a closed space than in the open air.

Parking the car in the garage while wet or covered with snow will increase humidity through slow evaporation. In such cases the car should be dried. Do not store large quantities of water in the garage. Make sure that the garage has windows or other openings to ensure adequate ventilation.





#### **Prolonged Inactivity**

If the car is to remain inactive over long periods, it is advisable to carry out the following operations:

- Clean and protect the painted areas with silicone wax. Coat the bright metal parts with a standard chrome preservant.
- Store the car in a covered, dry and ventilated place.
- Ensure that the parking brake is released.
- Disconnect the battery terminals.
- Remove the wiper blades and coat with talc.
- Open the door windows slightly.
- Protect the car using a non-plastic car cover. This should not be waterproof.
- Check the tyre inflation pressure periodically.
- Check the battery charge every 1½ months. When necessary, use a slow 24 hr. charge.
- Do not empty the cooling system.

FILAT Gruppo Veicoli Fiat - Assistenza Tecnica - 10134 TORINO (Italia) - Corso E. Giambone, 33 Fiat Auto S.p.A. Print No. 603.75.227 - VII - 1979 - 70.000 - Printed in Italy - Tipografia Torinese S.p.A.

The information contained in this publication is intended to be of a general nature only. The Fiat Company may at any time and from time to time, for technical or other necessary reasons, modify any of the details or specifications of the product described in this publication. To be sure of getting accurate, detailed and up-to-date information, an intending buyer should consult his nearest Fiat Dealer or distributor or branch.

F I A T

Direzione Commerciale - Assistenza Tecnica - 10134 TORINO (Italia) - Corso E. Giambone, 33 3rd Edition - Print No. 603.05.688 B - X-1979 - 8000 - Printed in Italy - Tipografia Torinese S.p.A. - Torino

